



## UNPACKING PROCEDURE

The owners manual on pages 14-18 details unpacking and preparing the mower for operation. However, it can be a little challenging actually getting a mower out of its crate. We have found the following procedure one of the easiest methods to “de-crate” a mower and hope you will find this useful.

Remove upper frame & carefully slit open the top of the protective plastic wrapping opening it out down to the ground. Cut the assorted ties and remove the seat, steering wheel and grass deflector and any other accessories (if included) from the machine. Lift the cutting deck lever so the deck is in the highest position.



Utilising a chain block or perhaps several willing friends or neighbors elevate the front of the machine to about 30 degrees then insert sturdy planks (about 3 meters in length) under the mower (both sides) until the plank ends are up against the front of the rear wheel.





Now lower the front of the mower onto the planks. (Front wheels on the planks and rear wheels still in the steel crate).

Disengage the brake and put the gearshift in neutral. Two people can now lift and roll the rear of the mower onto the planks then forward and off the frame.



Now proceed through the balance of the steps outlined in the manual (pages 14-18) to prepare the mower for use.

**NOTE:** For the sake of safety and reliable operation we recommended a thorough check is undertaken to tighten all nuts bolts screws and fasteners **BEFORE** operation. This includes checking the bolts retaining the blades under the mowing deck.

## HAPPY MOWING !

© Machines Gadgets and Gizmows Ltd

[www.MGG.co.nz](http://www.MGG.co.nz)